Outdoor Post Eye Light Control Instructions

758CT

LIGHT

CONTROL

WHITE

POWER SOURCE

BLACK

BI ACK

or RED

1. DISCONNECT POWER TO BRANCH CIRCUIT: Remove light fixture and slip the Light Control over the top of the post, wire according to diagram. Fasten using the gasket and lock nut provided making certain that the bottom of the light fixture is about 1/4" from the Light Control and does not cover or rest upon it.

DO NOT INSTALL THE LIGHT CONTROL WITH THE PHOTOCELL FACING ARTIFICIAL OR REFLECTED LIGHT.

This will cause the unit to cycle on and off at night (see Problem Solving).

2. It is normal for switch to take several minutes to turn off when first installed. To test "turn on" during day, cover eye with black tape or other opaque material. Do not cover with finger because light traveling through finger may be great enough to keep switch open. Test will take approximately 2 minutes.

Check the following before you replace an inoperative Light Control.

PROBLEM SOLVING: Light staving on during

daytime.

Light coming on too early or going off too late.
Light cycling on and

off during the day. Light cycling on and

off at night. Light not coming on at

night or turning on too late.

SOLUTION:

Make sure eye is receiving light and is not being shielded by overhang or mounted facing the ground. Occasionally lightning or severe line voltage surges may damage photoelectric switch. Same as above.

LIGHT FIXTURE

The red and black wires are wired wrong and should be reversed.

Light is being reflected into eye. It is essential that you shield of reposition switch to eliminate this condition.

The switch may be held off by external light source. Shielding or repositioning necessary.

Operation not affected by weather, moisture or temperature changes.

NOTE: This product uses incandescent, fluorescent, mercury vapor and sodium bulbs.

1 Year Warranty

AmerTac[™] warrants this product to be free from defects in material and workmanship for a period of 1 year from the date of purchase. AmerTac's obligations are limited to repairing or replacing any defective units and are effective only if such units are returned within 1 year of the purchase date, to AmerTac[™], 250 Boulder Drive, Breinigsville, PA 18031. Warranty void if damage is due to accident, negligence, misuse, alteration or improper installation. In no circumstance will AmerTac be liable for consequential or incidental damages relating in any way to this product.

Questions, ¿Preguntas?, La question? 1-800-777-0802

©2008 AmerTacTM 250 Boulder Drive Breinigsville, PA 18031 www.amertac.com

Made in China / Hecho en China / Fabriqué en Chine



