



TM1613DOLB

2-Outlet Outdoor Timer

Instruction Manual & Warranty

1. Setting On/Off Periods:

This timer can set up to 48 On/Off commands a day. Using your finger, a pen or screwdriver, pull up all the pegs that correspond to the desired “Off” period. For the desired “On” period, make sure the pegs are pushed down. Each peg represents 30 minutes; 2 pegs represents 1 hour.

2. Setting Time

Turn dial clockwise until triangular pointer is pointing at current time. Ensure that switch on the unit is set to TIMER ON position.

3. Connection:

Once the desired On/Off periods and current time are set, plug Timer into wall socket, and then devices’s plug into Timer. Ensure the wall socket and the device is turned on. The Timer will start to operate and switch the device on and off according to the pre-set On/Off commands.

4. Manual ON/OFF

The pre-set On/Off commands can be interrupted by using the manual override switch, located below the timer dial. When switched to the OUTLET ON position, connected device is switched on permanently. To reactivate the timer’s control of the device, turn the device switch on and set the timer’s override switch to TIMER ON. In case of power failure, reset the time of day as explained in step 2.

RATINGS:

15 Amps, 1875 Watts Resistive
10 Amps, 1250 Watts Tungsten
125V~, 60Hz
1/2 HP

5. Wall Mounting:

- If Outdoor Timer is mounted on outside wall or post it must be at least 3 feet above ground and close enough to be plugged into an electrical outlet receptacle suitable for wet locations. The outlets must face the ground.

-Place keyhole slots over screws and push Outdoor Timer down to lock into place.



One-Year Limited Warranty

AmerTac warrants to the original purchaser that this product will be free from defects in materials and workmanship for a period of one year from the date of purchase. Additional details are available at www.amertac.com. **Prop. 65 Warning:** This product contains chemicals known to the State of California to cause cancer and/or birth defects or other reproductive harm.

Garantie limitée de 1 an

AmerTac garantit à l’acheteur initial que, dans des conditions normales d’utilisation, ce produit sera exempt de défaut de matériaux et de fabrication pendant une période de 1 an à compter de la date d’achat. Des détails supplémentaires sont disponibles sur le site www.amertac.com.

Garantía Limitada de 1 Año

AmerTac le garantiza al comprador original que este producto estará libre de defectos en materiales y mano de obra por un período de 1 año a partir de la fecha de compra. Detalles adicionales disponibles a través de www.amertac.com.

AmerTac
250 Boulder Dr.
Breinigsville, PA 18031
610-336-1330

www.amertac.com

Made in China
© 2017 AmerTac™

I17-0009-A



CONFORMS TO UL STD 60730-1, 60730-2-7
CERTIFIED TO CSA STD E60730-1, E730-2-7
CUMPLE LA NORMA UL 60730-1, 60730-2-7
CERTIFICADO SEGÚN LA NORMA CSA E60730-1, E730-2-7
CONFORME À LA NORME UL STD 60730-1, 60730-2-7
CERTIFIÉ CONFORMÉMENT À LA NORME CSA STD E60730-1, E730-2-7