





WIRING DIAGRAM

A. Single sensor control




B. Multiple sensors control





MOUNTING

A. Assemble the sensor with fixture via the knockout hole.



B. Tighten the screw nut.



Note: For IP-66 fixture integration with SEN-3A-KO, ensure the rubber gasket is placed in between the fixture enclosure and sensor unit.

