

Touch Control Wiring Diagram

Models 90/2428, 90/2429

Step 1.

Turn Main Power Off or Un-plug Lamp from Wall Outlet.

Step 2.

Connect **White** Wire from Touch Control to **White** wire from Light Source.

Step 3.

Connect **Black** Wire from Touch Control to the **Black** wire lead from the main in-put power supply.

Step 4.

Connect **Red** Wire from Touch Control to the **White** lead from Main In-put ac Power supply and **Black** wire lead from Light Source.

Step 5.

Attached **Yellow** sensor wire with O-ring to the Lamp/Fixture Base.

