




L-PS-FR-3BK-30

Tools Needed



Pearl Series Puck Light

Part Number	Description and Use	Dimensions
L-PS-FR-3Color-Temp	Puck Light for Recess or Surface Mount	2-3/4" x 5/8"


NOTE

Dimmable with Task Lighting Wireless Control System or the Dimmable Power Supplies used with compatible wall dimmers. See pages 20-23 for wiring power supply to puck light.


Surface Mount




1. Remove Puck Light from housing by grasping the trim and firmly pulling.



2. Route fixture wires through center of housing toward power supply location; position wires in housing notch.




3. Secure housing to mounting surface with 2 screws, included.



4. Snap Puck trim into housing.


Recess Mount




1. Use a hole saw and cut a 2-1/2" hole through mounting surface.



2. Remove Puck Light from housing by grasping the trim and firmly pulling.



3. Route fixture wires through the hole toward power supply location.



4. Snap Puck trim into the hole.