

# Remote control Settings for Dimmable Sensor



## Remote # 86/219 for use with sensor 86/218

Display Panel for toggled settings



Button Settings

- 1) **Brightness**, 70%, 80%, 90%, 100%, Light Levels.
  - 2) **Hold Time**, 10s, 1M, 10M, 30M, Refers to the period the light remains at 100% Illumination after no motion is not detected.
  - 3) **Daylight**, 10Lx, 30Lx, 50Lx, 100Lx, The sensor can be set to only allow the light to illuminate below a defined ambient brightness threshold.
  - 4) **Sensitivity**, 20%, 50%, 75%, 100%, Sensitivity means detection coverage, it can be adjusted By toggling between above options.
  - 5) **Standby Dim**, 10%, 20%, 30%, 50%, This is the pre-setting dimming level you would like to have after the hold time in the absence of movement.
  - 6) **Standby Time**, +∞, 1M, 30M, 60M, Refers to the period the light remains at a pre-setting dimming level before it completely switches off in the absence of movement.
- ON/OFF:** Press and hold for 3sec until only the buttons on the first-row light up; press for 1sec to turn the light ON or Off.

**Brightness:** Press to adjust the dimming levels, 70%, 80%, 90%, 100%.

**Send:** Press the send button after the desired setting is being selected for each option .

**Hold Time:** Press to select between the pre-set options; 10s, 1m, 10m, 30m.

**Daylight:** Press and hold for 3sec until the daylight display lights up, Press to adjust the desired setting; 10Lx, 30Lx, 50Lx, 100Lx.

**Sensitivity:** Press to select the desired detection range; 20%, 50%, 75% 100%.

Note: The motion sensor does not have a sensitivity setting the default is 100%.

**Standby-Dim:** Press to adjust the stand-by dimming levels: 10%, 20%, 30%, 50%.

**Standby Time:** Press to adjust the standby time; +∞, 1min, 30min, 60min.

Note: the +∞ it means unlimited stand-by time.

**Reset:** By pressing the reset button, all the settings will change, which is brightness 70%/ Hold Time 10s/ Sensitivity 20%/ Daylight Threshold Disable/Stand-by dimming level 10%/ Stand-by time + ∞.

**Test:** The test button is for testing after the installation is completed, Pressing this button the sensor goes into test mode (hold time is the only 3s).

⊕ and ⊖: ⊕: Press to increase brightness(100%-0%); ⊖: Press to reduce brightness(100%-0%)

### NOTES:

- To change or add a setting the remote control must be on, Press the On/OFF button for 3sec; if you don't make any selection Within 10sec the indicator light will turn-off.
- When using the ON/OFF button except for the ON/OFF, Brightness and **SEND** Buttons will be disabled.
- When using the test button except for the TEST, Sensitivity, and **SEND** will be disabled.
- When making any setting changes most press the **SEND** button to save the setting.
- Light control priority Mode; the ON/OFF illumination values are 10/50Lx, 30/100Lx, 50/100Lx, 100/200Lx.
- Light control Threshold Mode; the ON/OFF illumination values are 10Lx/30Lx/50Lx/100Lx, when the light intensity is less than the set value, in the event of the presence of motion the light is turned on to the preset brightness.